

# Welch Allyn Scanners with new release

## USB Scanners:

Factory Default  
Terminal ID  
124 (scan each one individually)  
Save  
Add Prefix  
997C (scan each one individually)  
Save  
TAB Suffix

## Keyboard Wedge Scanners:

Factory Default  
Add Prefix  
997C (scan each one individually)  
Save  
TAB Suffix

Factory Default



Add Prefix



Terminal ID



9



1



9



2



7



4



C



Save



Tab Suffix

